



Trimpot RV1: Bourns 3362P, 50 ohms
 L7: 10 turns #24 on FB57-77. Secondary JP1 one turn.

For toroids, hold in the horizontal plane. Lower the first turn through the toroid.
 Then wind the lower wire in the clockwise direction.