

SOME USEFUL INFORMATION

Current FreeDV Software:
Will auto change received modes when monitoring a FDV signal.



FreeDV Software David Rowe:
<https://rowetel.com/downloads/freedv>

Remote SDRs:
Kiwi SDRs: <http://kiwisdr.com/public/>
Web SDRs: <http://websdr.org/>
(Both have maps locating active SDRs)



Virtual Cables:
Various available,
A free version: vac415

ICOM Drivers for USB connection.
Must be installed on your computer, before USB connection with transceiver.
For IC-7300-
https://www.icomjapan.com/support/firmware_driver/3248/

There is also a USB Installation guide available on ICOM Japan



3 COMPUTERS!



VIRTUAL CABLES

VIRTUAL CABLES