



RCBus extension pin functions:

	P37	P38	P39	P77
Backplane	USER1	USER2	USER3	USER5
RCBus-2014	/INT1	IEI	IEO	/INT2
RCBus-Z80	/FIRQ	E	RW	n/a
RCBus-68xx	/MEMEN	CRUIN	CRUCLK	n/a