

Magic Lantern 0.2 for Canon 550D, firmware 1.0.9 Installation

<http://magiclantern.wikia.com/550D>

May 25, 2011

Magic Lantern is an open (GPL) framework for developing enhancements to the amazing Canon 5D Mark II and 550D/T2i digital SLRs. Magic Lantern is being [developed](#) by a small team, helped by a very enthusiastic and respectful [user community](#).

Initial version by [Trammell Hudson](#) (the author and lead of Magic Lantern project)

Main developer for 550D branch: [Alex](#)

Crypto tools and 550D/1.0.9 port by [Arm.Indy](#)

Code review and insights by [AJ](#)

Patches by [piersg](#), [nandoide](#), [stefano](#), [trho](#), [deti](#), [tapani](#), [phil](#)

Card tools by [Pel](#), [Zeno](#), [lichtjaar](#)

Cropmarks by [CameraRick](#), [Robert](#), [bwwd](#), [turbincarpus](#)

Tutorials by [sawomedia](#), [Renny](#), [Jeremy](#), [Daniel](#), [Dod3032](#), [MediaUnlocked](#), [3615geek](#), [CineDigital.tv](#), [jeveuxdoncjevilmé](#)

Thanks to all the users who [provided feedback](#) and [reported bugs](#)!

Special thanks for people who [donated](#) in order to help the development of Magic Lantern; your help is very much appreciated!

Also, thanks to the [CHDK team](#) and all the [contributors and donors for the 5D2 Magic Lantern](#)!

Magic Lantern is being developed by independent film makers in our spare time and at risk to our beloved cameras. We hope that it saves you time and aggravation on set, and we'd appreciate your support. You can help by [donating via PayPal](#), or through equipment donations. You can also [contact me \(Alex\) via email](#). Thanks!

[Donate](#)

Contents

WARNING	3
Important notes	3
Introduction	3
Installing Magic Lantern for 550D firmware 1.0.9 for the first time	4
Step 0. Downloading	4
Step 1. Enabling bootflag	4
Step 2. Making the SD card bootable	5
Mac OS X	5
Windows	5
Linux and Mac OS X (command line)	6
Step 3. The last one :)	6
Troubleshooting	7
Installing updated Magic Lantern builds	7
Uninstalling Magic Lantern	7
Uninstalling ML from one card	7
Uninstalling ML from the camera	8
Older versions (archived)	8
550D/1.0.9	8
550D/1.0.8	8
Official builds from Trammell Hudson	8
Unofficial (experimental) builds	8
Risks	9
Source code	9

WARNING

```
.*****
*
* THIS IS DANGEROUS AND MIGHT DAMAGE YOUR CAMERA. *
* NO WARRANTIES. NO GUARANTEES. DO NOT TAUNT. *
*
*****
```

If you are not comfortable with this, stop reading and delete the software before you are tempted to try running it on your camera.

To repeat this important point:

```
.*****
*
* THIS IS DANGEROUS AND MIGHT DAMAGE YOUR CAMERA. *
* IF IT BREAKS, YOU GET TO KEEP BOTH PIECES. *
*
*****
```

Important notes

- EyeFi cards [are known to cause problems](#), so it's better to use normal cards. See also [this message from fe50](#).
- If you have a bootable SD card and have the DISKBOOT flag set in the camera (which the installer does), and you do not have an AUTOEXEC.BIN file on the card the camera **WILL NOT BOOT!** It will hang and not wake up until the battery is removed.
- If you encounter a "locked up" camera, **quickly remove the battery**. Otherwise the ARM might be in a tight-loop and get very hot, very quickly. Your battery will run down and your LCD might show some discoloration.
- When in doubt, remove the battery and reboot.
- **And, remember that this software can damage or destroy your camera.**

Introduction

There are 2 ways of running user code on the 550D/T2i/Kiss X4:

1. using the update process with a .fir file, which must be digitally signed.
2. using the bootdisk process: the autoexec.bin file is loaded and executed. This file does not have to be signed, but the bootdisk flag must be enabled in the camera.

To install Magic Lantern on your camera, you must download the right magiclantern for your firmware: 1.0.8 or 1.0.9. The recommended way is to upgrade your camera to 1.0.9 in order to get the latest features.

No development will be done on 1.0.8 any more. Magic Lantern does not work at all with earlier firmware versions.

Installing Magic Lantern for 550D firmware 1.0.9 for the first time

Make sure you have the Canon Firmware 1.0.9 first! Running Magic Lantern on an incorrect firmware version may brick your camera!

If you already use a previous version of Magic Lantern for 550D firmware **1.0.9**, it's easy. Download the latest ML and unzip everything on your SD card. Done. Enjoy!

If you already use Magic Lantern for 550D/1.0.8, format your card, upgrade camera firmware to 1.0.9 and follow the ML install steps.

Step 0. Downloading

- Download this release: [magiclantern-0.2.0.rc1.550d.fw109.zip](#).
- Read [this discussion thread](#) for more info.

Step 1. Enabling bootflag



- Remove any accessories from your camera (such as battery grip or external flash)
- Restore your camera to default settings (Clear all camera settings, from Wrench 3 menu)
- Format the SD card from the camera (low level, from Wrench 1 menu)
- Copy `magiclantern.fir` from the zip archive on the SD card
- Launch the firmware update process. For this, start the camera and select `Firmware ver 1.0.9` from the Wrench 3 menu (must be in manual or P mode to select)
- The installer (`magiclantern.fir`) will enable the bootdisk flag in NVRAM by calling the `bootdisk_enable()` function from Canon firmware.
This is the **only** persistent change to your camera, which can be reverted.
- Once the drive light has gone off and stays off for a few seconds, remove the battery.


Step 2. Making the SD card bootable

The file `autoexec.bin` can be launched if the bootdisk is enabled AND the SD card is “prepared” with special values written in boot sector:

- for FAT16 cards: EOS_DEVELOP at offset 43 and BOOTDISK at offset 64
- for FAT32 cards: EOS_DEVELOP at offset 71 and BOOTDISK at offset 92
- for EXFAT cards: EOS_DEVELOP at offset 130 and BOOTDISK at offset 122; there’s also a checksum, see [Bootdisk](#) for details.

Do not put an “prepared” (bootable) card without “autoexec.bin” in the camera! (it won’t boot and you’ll have to take the battery out).

Mac OS X



[Video:MAGIC LANTERN 1.0.9 HACK INSTALL WITH A MAC FOR CANON T2I OR 550D](#)

Use **MacBoot** by [Dave Mitchell](#). MacBoot works with FAT16, FAT32 and EXFAT cards.

Select your SD card drive, check `Make DSLR-bootable` and hit Prepare.


If MacBoot does not work, try `make_bootable.sh` (scroll down) and be sure to report the problem to Dave.

Windows

[Video:Magic Lantern Installation Tutorial for Canon 550D / Rebel T2i](#)

[Video:Tutorial 5 - Magic Lantern by Dod3032](#)

Use [EOScard](#) (thanks [Pel!](#)). It works with FAT16, FAT32 and EXFAT cards. You need to have Administrator rights on your Windows user account.



Select your SD card drive, check EOS_DEVELOP and BOOTDISK and hit Save.

If the antivirus [is complaining](#), put it on Game Mode or try another operating system ;)

Linux and Mac OS X (command line)

You can use `make_bootable.sh`, which is included in the archive. If you don't know how to run scripts, see [here](#).

Open the file and change the following line in order to indicate your SD card device:

```
# change this
dev=/dev/disk1s1
```

- To find the correct `/dev/` entry under **OS X** type:

```
diskutil list | grep FAT
```

That will list all mounted FAT disks, the `/dev/` entry is the last column. Note also that under OS X this script will leave the card unmounted, eject and reinsert it to re-mount it.

- To find the correct `/dev/` entry under **Linux** type:

```
mount | grep fat
```

and choose the one labeled `EOS_DIGITAL`.

- For EXFAT cards, see [this thread](#).

Run the script from the terminal:

```
bash make_bootable.sh
```

If it doesn't have enough permissions, run it as root:

```
sudo bash make_bootable.sh
```

Step 3. The last one :)

- Delete `magiclantern.fir`.
- Copy `autoexec.bin` and `cropmks` on your SD Card. Older builds may require some BMP files and `magic.cfg`.
- Put the card in the camera.
- Switch on your camera, and Magic Lantern (`autoexec.bin`) will boot.

As long as you had enabled the `BOOTDISK` flag once, your card is "prepared"; the camera will try to load any `autoexec.bin`. The `.fir` file is not needed any more, unless for some reason you will want to retry the installation process.

Troubleshooting

- Check if all doors are closed. The camera will not boot if the SD slot door is open!
- If Magic Lantern does not work (i.e. no new features are noticed), repeat Step 2. This means your card is not bootable. Also try with an older (FAT16) card, try with another card reader, another PC or another operating system.
- **DO NOT repeat the firmware upgrade step with “magiclantern.fir”!** There may be a firmware update counter like on the 7D, and you may end up with a bricked camera.
- If the camera does not boot (seems dead), **remove the battery and the card**. Then put the battery back and try to boot the camera without card. Then put a formatted card in the camera and try to boot **without** Magic Lantern. Only after you are sure the camera is OK, you can try to see what’s wrong with Magic Lantern.
- Again, **NEVER let a prepared card without a working autoexec.bin on it, remove the battery immediatly during 5 seconds, switching off is not enough !!!**
- Look in the [issue tracker](#) for similar problems; if you can’t find the solution, create a new issue there.
- Always use *safely remove hardware* when copying files to your SD card; otherwise, you may end up with a corrupted file system. The PC may not notice it, but the camera may fail to load `autoexec.bin` or to detect cropmarks.

Installing updated Magic Lantern builds

[Video:550D T2I Magic Lantern: Installing New Builds, Offical / ML in parallel, Deinstalling ML](#)

[Video:MAGIC LANTERN 1.0.9 FIRMWARE HACK:UPDATE Q&A](#)

After you’ve installed ML, you can get updated builds; just unzip them on the SD card (overwrite old files).

It’s highly recommended to install an updated build, usually the last one. They are announced first on the [ML mailing list](#) and on [Vimeo Magic Lantern User Group](#).

Make sure you have the correct firmware version!

Uninstalling Magic Lantern

Uninstalling ML from one card

Format the card from the camera, and Magic Lantern will be gone (only from that card, of course).

Don’t just delete the Magic Lantern files from the card! If you do, the camera won’t boot and you’ll have to take the battery out.

Uninstalling ML from the camera

You don't have to do this unless you are asked to do so by ML developers. For most users, formatting the card will be enough to uninstall ML.

If you know what you are doing, put this in `magic.cfg` to reset the DISKB00T flag from the camera:

```
magic.disable_bootdiskf = 1
```

Older versions (archived)

550D/1.0.9

- 3 Dec 2010: [magiclantern-0.1.9-rc0_550d_fw109.zip](#)

550D/1.0.8

No further development will be done on the 1.0.8 firmware.

Official builds from Trammell Hudson

- [Announcing pre-alpha firmware](#)
- RC1 release: [magiclantern-550d.rc1.zip](#)
- 8 Aug 2010: [Update 550D beta, now with gain control](#)

Unofficial (experimental) builds

- 11 Nov 2010: [magiclantern for 550D, compiled with shorter config file](#)
- 23 Nov 2010: [Recording Internal and external audio simultaneously](#)
- 07 Dec 2010: [fixed cropmarks](#)
- 09 Dec 2010: [enabled zebras and histogram](#)
- 11 Dec 2010: [GUI menus & lots of extras](#)
- 12 Dec 2010: [enabled QScale and spotmeter](#)

Risks

- This firmware does a (very small) (semi-)permanent change to your camera: it changes the DISKBOOT flag, which is stored in NVRAM. This change can be reverted (see the mailing list and bootflags.c).
- There are no confirmed reports of Magic Lantern doing permanent damage on the 550D. However, there are reports on CHDK forum that some users [bricked their 350D](#), most probably by installing a hack on the wrong firmware version. There are also lots of reports of camera refusing to boot after installing ML; this happens because they have tried to start the camera from a bootable (i.e. prepared) card without autoexec.bin.
- Starting the camera with a bootable card without an autoexec.bin **will cause symptoms similar to a bricked one** (it will not boot). This may scare you. If it happens, **take the battery out quickly** and the camera should be fine. There are many reports about cameras which behave like being bricked, when in fact it was just autoexec.bin missing. That's why you should read the install instructions carefully.
- On certain cameras, there are power management issues (i.e. if you turn off the camera or let it go to standby, it won't start any more). Make sure you don't have these problems; if you do, take the battery out after each shooting session!
- Even if you don't have power issues, it's a good idea to take the battery out when you don't use the camera.
- The biggest risk is when experimenting with source code without knowing what you are doing. Calling certain functions or calling them at the wrong moment can be dangerous.
- Risks are low with pre-built binaries, since we test them on our cameras before making them public.
- Risks are minimal with official versions (from the main repo), since they get tested by many users before releasing them.

That being said, Magic Lantern for 550D was downloaded over 10000 times (without counting downloads from the mailing list or from other sites), and most users run it successfully and use it for production, not only for testing.

Source code

You can build your own AUTOEXEC.BIN files with [the 550d branch of the source code](#):

```
hg clone -r 550d https://bitbucket.org/hudson/magic-lantern
```

There is **no** Canon source or object code in the Magic Lantern tree and we do **not** distribute ROM dumps since they contain code that is copyright by Canon. If you have the camera in hand, you can make your own dump for analysis and use [this IDC database](#) to add symbols to it.

If you want to compile your own AUTOEXEC.BIN, check the following wiki pages:

- [For Developers](#)
- [Build instructions/550D](#)
- [550d dev](#)